

		St ²	Adv.				P	S	A	M	S	▲	⚡	☾	SP											📺	📶	
			Adv.	📺	📺	📺									📺	📺	📺	📺	📺	📺	📺	📺	📺	📺	📺			📺
SETUP DIGIT STAB ³	📺 ₁	✓ ³								✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📺 ₁		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📺 ₂									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📺 ₂		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	FRA		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
SKÆRMINDSTILLELING	VISEKS. MAN. TIL.		✓	✓	✓				✓																		✓	
	FORHÅNDSVIS BILLEDEFFEKT	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	FOKUSKONTROL		✓		✓	✓	✓	✓	✓																			

- 1 Fastsat til **OFF**.
- 2 Fastsat til **ON**.
- 3 Skifter automatisk alt efter indstilling.
- 4 Ikke tilgængelig i indstillingerne 📺 **FREMÆVNINGSTAST**, 📺 **DÆMPET** eller 📺 **DYNAMISK TONE**.
- 5 Kun kompatible objektiver.
- 6 Trådløs, fjernstyret fotografering.