



		SR <sup>+</sup>	Adv.				P	S	A	M	☁	⬆	✂	☾	SP											📷	📶 <sup>6</sup>			
			AGW	📺	📺										☁	☁	☁	☁	☁	☁	☁	☁	☁	☁	☁			☁	☁	☁
ESTABIL. IMAGEN <sup>5</sup>	📷 <sub>1</sub>	✓ <sup>3</sup>								✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 <sub>1</sub>	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 <sub>2</sub>									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 <sub>2</sub>		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	NO		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CONFIG. PAN-TALLA	VER EXP. M. MANUAL		✓	✓	✓				✓																				✓	
	VER EFECTO IMAGEN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	COMPROB. ENFOQUE		✓		✓	✓	✓	✓	✓																					

- 1 Fijado en **OFF**.
- 2 Fijado en **ON**.
- 3 Cambia automáticamente en función del modo.
- 4 No disponible en los modos 📷 **TONO ALTO**, 📷 **CLAVE BAJA** o 📷 **TONO DINÁMICO**.
- 5 Únicamente objetivos compatibles.
- 6 Fotografía remota inalámbrica.