

# 各撮影モードで使用できる機能について

各撮影モードで使用できる機能は以下のとおりです。

◆ ✓ が付いている機能でも、選択できない設定値がある場合があります。

◆ 撮影条件によっては機能が制限される場合があります。

		Adv.	SP										REC	WIFI				
			AEW	□	■	P	S	A	M	(REC)	▲	▼	○	×	◆	●	★	TEXT
露出補正		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
連写		✓				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ブラケティング						✓	✓	✓	✓									
フォーカス設定	フォーカスエリア選択		✓			✓	✓	✓	✓	✓								✓
	MF					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	+					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	×				✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	□				✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	☒				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	AF+MF					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	顔検出 / 瞳 AF 設定	顔検出	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	瞳 AF	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
AF補助光		✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
感度	AUTO1~3				✓	✓	✓	✓	✓	✓								✓
	H (25600)					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	H (12800)					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	6400~1000				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	800		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	640~400		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	320~200		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
L (100)					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
画像サイズ	L	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	M	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	S	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
画質モード	FINE/NORMAL	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	RAW					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ダイナミックレンジ	AUTO	✓ <sup>3</sup>	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	R100		✓	✓	✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	R200		✓ <sup>4</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	R400		✓ <sup>4</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
フィルムシミュレーション	Std <sup>1</sup>	✓	✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VF <sup>2</sup> /S <sup>3</sup> /C <sup>4</sup>				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	B <sup>5</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
セルフタイマー	2秒/10秒	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	スマイル	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	カップル	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	グループ	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ホワイトバランス			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
カラー					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
シャープネス					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ハイライトトーン					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
シャドウトーン					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
ノイズリダクション					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
カスタム保存					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
MFアシスト	スタンダード		✓	✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	フォーカスピーキング				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
測光	□	✓ <sup>3</sup>	✓ <sup>3</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	■				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	□				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
フラッシュ設定	オート	✓	✓			✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓
	△	✓	✓			✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓
	S <sup>4</sup>	✓	✓			✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓
	REC <sup>5</sup>	✓	✓			✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓
	■ <sup>6</sup>	✓	✓			✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓
	③	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	AUTO					✓				✓	✓	✓	✓	✓	✓	✓	✓	✓
	① <sup>7</sup>	✓				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	② <sup>8</sup>					✓				✓	✓	✓	✓	✓	✓	✓	✓	✓
	③ <sup>9</sup>					✓				✓	✓	✓	✓	✓	✓	✓	✓	✓
プレ防止モード <sup>5</sup>	OFF	✓	✓ <sup>1</sup>	✓	✓ <sup>1</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	ON	✓				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	(,)	✓ <sup>3</sup>								✓	✓	✓	✓	✓	✓	✓	✓	✓
	(,)	✓				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
表示設定	マニュアル時モニター露出反映		✓	✓	✓					✓								✓
	モニター撮影効果反映	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	フォーカスチェック		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

1 OFF に固定されます。

2 ON に固定されます。

3 各モードで自動的に設定されます。

4 ハイキー / ローキー / ダイナミックトーンのときは、選択できません。

5 装着するレンズによって異なります。

6 ワイヤレス通信のリモート撮影。