

		St+	Adv.				P	S	A	M	[Icon]	[Icon]	[Icon]	[Icon]	SP												[Icon]	[Icon]		
			Adv	[Icon]	[Icon]	[Icon]									[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]			[Icon]	[Icon]
손떨림보정모드 ³	[Icon] ₁	✓ ³								✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	[Icon] ₁		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	[Icon] ₂									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	[Icon] ₂		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	OFF		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
화면 설정	수동 모드에서 노출 미리보기		✓	✓	✓				✓																				✓	
	사진 효과 미리보기	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	포커스 체크		✓		✓	✓	✓	✓	✓																					

- 1 OFF로 고정되었습니다.
- 2 ON으로 고정되었습니다.
- 3 모드에 따라 자동으로 변경됩니다.
- 4 [Icon] 하이키, [Icon] 로우-키, 또는 [Icon] 다이내믹 톤 모드에서 사용할 수 없습니다.
- 5 호환 가능한 렌즈만.
- 6 원격 무선 촬영.