



		St <sup>+</sup>	Adv.				P	S	A	M	(G)	▲	⚡	☾	SP										📷	📶 <sup>6</sup>										
		📷 <sup>3</sup>	🔊	📷	📷										📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷	📷				
BILDSTAB LÄGE <sup>5</sup>	📷 <sub>1</sub>	✓ <sup>3</sup>									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			
	📷 <sub>2</sub>		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	📷 <sub>3</sub>										✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	📷 <sub>4</sub>		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	AV		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
SKÄRM- STÄLLNING	FRHG. EXP MAN. LG.		✓	✓	✓				✓																									✓		
	GRANSKA BILDEFFEKT	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	FOKUS KONTROLL		✓		✓	✓	✓	✓	✓	✓																										

1 Låst vid **OFF**.

2 Låst vid **ON**.

3 Ändras automatiskt beroende på läget.

4 Ej tillgängligt i läge 📷 **HIGH-KEY**, 📷 **LÅGDAGER** eller 📷 **DYNAMISK TON**.

5 Endast kompatibla objektiv.

6 Trådlös fjärrstyrd fotografering.