

		SR ⁺	Adv.				P	S	A	M	Ⓢ	▲	✂	☾	SP										Ⓢ	Ⓢ			
			Adv	☐	☐	☐									☐	☐	☐	☐	☐	☐	☐	☐	☐	☐			☐	☐	☐
MODALITA' IS ⁵	☐ ₁ ☐	✓ ³								✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	☐ ₁		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	☐ ₂ ☐									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	☐ ₂		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	OFF		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
IMPOSTAZ. SCHERMO	ANTEPR. ESP. MAN.								✓																			✓	
	ANTEPRIMA EFFETTO IMM.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	CONTROLLO FUOCO			✓	✓	✓	✓	✓	✓		✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		

- 1 Fisso su **OFF**.
- 2 La sensibilità viene regolata automaticamente, a prescindere dall'opzione selezionata.
- 3 Cambia automaticamente in base alla modalità.
- 4 Non disponibile in modalità **HIGH-KEY**, **LOW-KEY** o **TONI DINAMICI**.
- 5 Solo obiettivi compatibili.
- 6 Fotografia wireless in remoto.