

		SR ⁺	Adv.				P	S	A	M	🔇	📶	🔍	🌙	SP										👤	📶		
			Adv	📷	📺	📺									📷	📷	📷	📷	📷	📷	📷	📷	📷	📷			📷	📷
BILDSTAB LÄGE ⁵	📷 ₁	✓ ³								✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 ₁		✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 ₂									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	📷 ₂		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	AV		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
SKÄRMINSTÄLLNING	FRHG. EXP MAN. LG.								✓																		✓	
	GRANSKA BILDEFFEKT	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	FOKUSKONTROLL			✓	✓	✓	✓	✓	✓		✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	

- 1 Låst vid **OFF**.
- 2 Känsligheten justeras automatiskt oavsett vilket alternativ som valts.
- 3 Ändras automatiskt beroende på läget.
- 4 Ej tillgängligt i läge 📷 **HIGH-KEY**, 📷 **LÅGDAGER** eller 📷 **DYNAMISK TON**.
- 5 Endast kompatibla objektiv.
- 6 Trådlös fjärrstyrd fotografering.