

有关照相机设定限制的信息

下表列出了每种拍摄模式下的可用选项。某些选项可能不适用于在特定模式下支持的项目，且根据拍摄环境的不同，功能可能会被限制。

		SR+	Adv.	P	S	A	M	S	▲	🚶	🌙	🌞	🌧️	🌲	🏠	🏡	🍷	🌸	TEXT	📶	📶			
曝光补偿		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
连续拍摄		✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
包围曝光					✓	✓	✓	✓																
AF/MF 设置	聚焦区域		✓	✓	✓	✓	✓	✓														✓		
	对焦模式	MF		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
		+			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
		☒		✓ ³	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
		☑	✓ ³		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	AF+MF			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			
脸部识别/眼睛识别设置	脸部识别	✓	✓		✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓			✓		
	眼检测 AF	✓	✓		✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓					
AF辅助灯		✓	✓		✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
ISO	自动1-3		✓ ²	✓	✓	✓	✓	✓	✓													✓		
	H (25600)				✓	✓	✓	✓	✓														✓	
	H (12800)				✓	✓	✓	✓	✓														✓	
	6400-1000			✓	✓	✓	✓	✓	✓														✓	
	800		✓	✓	✓	✓	✓	✓	✓														✓	
	640-400		✓	✓	✓	✓	✓	✓	✓														✓	
	320-200		✓	✓	✓	✓	✓	✓	✓														✓	
图像尺寸	L	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	M	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	S	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
图像质量	FINE/NORMAL	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	RAW				✓	✓	✓	✓	✓													✓		
动态范围	自动	✓ ³	✓	✓	✓	✓	✓	✓	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³		
	R100		✓	✓	✓ ³	✓	✓	✓														✓		
	R200		✓ ⁴	✓	✓	✓	✓	✓														✓		
胶片模拟	R400		✓ ⁴	✓	✓	✓	✓	✓														✓		
	SDR	✓	✓ ³	✓	✓	✓	✓	✓	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³		
	📷/📷/📷	✓		✓	✓	✓	✓	✓														✓		
	📷	✓		✓	✓	✓	✓	✓														✓		
自拍	2秒/10秒	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	微笑	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	朋友	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	组	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
白平衡				✓	✓	✓	✓	✓														✓		
色彩					✓	✓	✓	✓														✓		
锐度					✓	✓	✓	✓														✓		
高光色调					✓	✓	✓	✓														✓		
阴影色调					✓	✓	✓	✓														✓		
降噪功能					✓	✓	✓	✓														✓		
自定义设定					✓	✓	✓	✓														✓		
手动聚焦助手	标准			✓	✓ ³	✓	✓	✓		✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓		
	峰值对焦				✓	✓	✓	✓		✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓		
测光	☒	✓ ³	✓ ³	✓	✓	✓	✓	✓	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³	✓ ³		
	☑				✓	✓	✓	✓														✓		
	☐				✓	✓	✓	✓														✓		
闪光灯设置	闪光灯模式	红眼修正关	自动	✓	✓		✓	✓	✓			✓										✓		
			🔴	✓	✓		✓	✓	✓	✓			✓										✓	
			🔴		✓		✓	✓	✓	✓			✓										✓	
			🔴	✓	✓	✓	✓	✓	✓	✓	✓ ³	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
			🔴	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	红眼修正开	AUTO	✓			✓	✓	✓	✓	✓			✓										✓	
		👁	✓			✓	✓	✓	✓	✓			✓										✓	
		👁	✓			✓	✓	✓	✓	✓			✓										✓	
		👁	✓			✓	✓	✓	✓	✓			✓										✓	
		👁	✓	✓	✓	✓	✓	✓	✓	✓	✓ ³	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
红眼修正	关	✓	✓ ¹	✓	✓ ¹	✓	✓	✓	✓	✓ ¹	✓ ¹	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
	开	✓			✓	✓	✓	✓	✓			✓										✓		
防抖模式 ⁵	手动模式下预览曝光							✓														✓		
	预览图片效果		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	对焦确认				✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
					✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	

- 1 固定为 OFF。
- 2 无论选择了何种选项，感光度均自动调整。
- 3 根据模式自动改变。
- 4 在 🌞 高调、🌧️ 暗调 或 🌲 动态色调 模式下不可用。
- 5 仅适用于兼容镜头。
- 6 无线遥控拍摄。