

Restrictions on Camera Settings

The options available in each shooting mode are listed below. Some options may not be available for the items that are supported in any given mode, and function may be restricted depending on shooting conditions.

		Sh ³	Adv.				P	S	A	M	(⊗)	▲	✖	⌚	SP								TEXT	MOVIE	WIRELESS
IS MODE ⁵			Adv.	Scene	Image	File									Sh ³										
SCREEN SETUP	(i) ₁ (o)	✓ ³									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	(i) ₁		✓				✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	(i) ₂ (o)										✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	(i) ₂		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	OFF		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PREVIEW EXP. IN MANUAL MODE			✓	✓	✓						✓														✓
PREVIEW PIC. EFFECT		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
FOCUS CHECK			✓		✓	✓	✓	✓	✓	✓	✓														

1 Fixed at OFF.

2 Fixed at ON.

3 Changes automatically depending on mode.

4 Not available in HIGH KEY, LOW KEY, or DYNAMIC TONE mode.

5 Compatible lenses only.

6 Wireless remote photography.