

FUJIFILM

DIGITAL CAMERA

X-E5

New Features Guide

Version 1.10











Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

<https://fujifilm-x.com/support/download/firmware/cameras/>

Contents

The features listed below have been added, deleted, or updated in X-E5 firmware version 1.10. For the latest manuals, visit the following website.

<https://fujifilm-dsc.com/en/manual/>

No.	Description	X-E5 	See 	Ver.
1	 WIRELESS COMMUNICATION has been deleted from  SHOOTING SETTING ,  MOVIE SETTING , and  PLAY BACK MENU .	179 202 244	—	1.10
2	The pairing procedure between the camera and smartphone has been changed.	255	1	
3	WIRELESS COMMUNICATION has been deleted from the features that can be assigned in  BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING and POWER ZOOM LENS FUNCTION (Fn) SETTING .	311 341 344 347 349	—	
4	 WIRELESS COMMUNICATION has been deleted from  BUTTON/DIAL SETTING >  Fn1 BUTTON SETTING .	320	—	

Changes and Additions


Changes and additions are as follows.

X-E5 Owner's Manual: 255


Ver. 1.10

Connecting to a Smartphone

Pair the camera with the smartphone and connect via Bluetooth®.


- 1 Press and hold the  (Bluetooth) button.

The Bluetooth setting menu is displayed.




- You can also display the menu by pressing and holding the **DISP/BACK** button during playback.
- You can also pair the camera with the smartphone through the **Bluetooth & FUNCTION (Fn) SETTING** that is displayed by pressing and holding the **DISP/BACK** button when the camera is in shooting mode.

- 2 Highlight **PAIRING** and press **MENU/OK**.



- 3 Launch the app on the smartphone and pair it with the camera to display a code on the smartphone and the camera. Confirm that both codes match to pair.

A smartphone icon and a white Bluetooth icon will appear in the camera display when a connection is established.



- Once the devices have been paired, the smartphone will automatically connect to the camera when the app is launched.
- Disabling Bluetooth when the camera is not connected to a smartphone reduces the drain on the battery.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

<https://fujifilm-x.com>

